

Updating Insight® Software

Updating software may cause the Foresight option to be disabled. If you have purchased Foresight, contact Headsight before updating software.

1. You will need:
 - SD memory card (2GB or less)
 - Means of loading SD memory Card (computer with SD memory card drive, or usb drive with a usb to SD card memory adapter, or preloaded SD memory card from Headsight)
 - Small allen wrench or screwdriver
2. Load SD card with new software files
 - Place insightf.hex in the root directory of SD card (ex. E:\insightf.hex)
 - Do not change file names
3. If you do not have the new files you may
 - Download updated software from www.headsight.com
 - Request pre-loaded SD card from Headsight, Inc.
4. Disconnect all header connections from combine
5. Remove 4 screws from rear of Insight box - remove rear cover
6. Insert programmed SD card into SD card slot on rear of board
7. Power Insight
 - Connect all wiring to combine
 - Turn on key switch
8. Wait for software to download
 - Yellow light will blink while download is in progress
 - Green light will turn on solid when download is complete
9. Verify update is successful
 - Go to >>About Insight>>Software Version and read software version number
10. Remove power from Insight
 - Turn off key
11. Remove SD card
12. Reinstall rear cover
 - Fasten with screws