

HEADSIGHT® CAT POLY INSTALLATION GUIDE

3529 Fir Rd Bremen, IN 46506 574.546.5022



End Snoot Skid W/ Spacer and M10 x 60 Bolt



End Snoot Complete

Trim Skid Shoe if necessary to clear arm

End Snoot w/ Sensor in Place



CAT Center Snoot (Original)

CAT End Snoot
SWITCH L & R Curved Bars From
Original End Snoots OR Replace
w/ Straight Center Bars (Recommended).

CAT Center Snoot



Sensor Mounted on Curved End Snoot Bar
M10 x20 Countersunk Allen head bolts

