


# TS CNH Poly

Manual 09052002a

Case 2000 & 3000 series / All NH poly

1. Remove the cast iron snout tip from the snout.
2. Cut out the poly as shown
  - o Use a large drill bit to make rounded corners to avoid weakening snout.
3. Attach sensor to mounting bracket using provided hardware.



The sensor should be as far into the snout as possible without causing the arms to rub the bottom of the snout frame.

4. Insert bracket between cast iron snout tip and snout as shown. Fasten with provided hardware.



**HEADSIGHT INC.**  
HARVESTING SOLUTIONS



# Crop sensor mounting kit



- 1- B2713 -Mounting kit complete
  
- 1- HT2713 -Bracket
- 2- 08200124 -Bolt M10x25
- 2- 08200134 -Bolt Hex 5/16" x .75"
- 2- 08200133 -Washer 5/16"
- AR- 08200107 -Screws
- AR- 08100101 -Cable clamp small
- AR- 08100102 -Cable clamp large
- AR- 08300102 -Zip ties