

TS Ghoff Poly

Manual 09052007a

All new Geringhoff poly

1. Remove the Geringhoff skid from the snout tip.
 - o Be careful to keep the retaining nut that fastens the two rear bolts.
2. Notch the bottom side of the snout tip as shown.
 - o Drill corners of the hole then cut between them to prevent sharp corners.



3. Attach the sensor to the mounting bracket as shown.



4. Attach bracket to snout.
 - o Reuse original hardware.

Crop sensor mounting kit



1-	B2716	-Mounting kit complete
1-	HT2716	-Bracket
2-	08200134	-Bolt Hex 5/16" x .75"
2-	08200133	-Washer 5/16"
AR-	08200107	-Screws
AR-	08100101	-Cable clamp small
AR-	08100102	-Cable clamp large
AR-	08300102	-Zip ties