


Updating Software



If you are running Headsight's Horizon header height control, select the WiFi network of the Horizon base unit and it will automatically pass the update to Truesight as well. If you are not running Horizon, select the Truesight WiFi Network.

Updating with Techlink™ App

1. Download Headsight Techlink App on your iDevice or Android from the App store.
 - Must have Horizon 2.10.0 or later software
 - Login in following on screen instructions
 - Then go to Help Info to learn how to use app.



Updating with USB

1. Download latest version from website.
2. Unzip files, copy file insght2.bin onto root directory on USB flash drive.
3. Plug USB flash drive into USB port on Truesight 2 unit in combine cab.
 - If unit is not yet powered up, cycle key on combine
 - It should start blinking yellow shortly after applying power. If this doesn't happen, unplug and plug the Truesight 2 power.
4. Wait until Truesight 2 unit has a green indicator light (should be no longer than 5 min)
5. You can now safely remove the USB flash drive.
 - Be sure to replace USB cover cap
6. Wait for Truesight 2 to appear on VT
 - A power cycle might be needed after update
7. Your Truesight 2 is now updated. Please verify that your Truesight 2 initial settings are correct.

If your Truesight 2 units fail to update you must do a complete format on USB drive to a (FAT) file type and then recopy insght2.bin to root directory.